

Installation clearances

All dimensions are in millimetres (mm). Refer to the installation manual before fitting.

Clearance	Code	Dinder 60	Dinder 60 Freestanding
From rear wall	dR	250	250
From side walls	dS	200	200
From top	dC	350	350
From bottom	dB	50	50
From floor in front	dF	500	500
Side radiation area	dL	250	250
From front walls	dP	2000	2000

